

H8マイコンボードF0293ピン割当表



CN1			CN3		
1	AVcc		1	P42	
2	AVref		2	P43	
3	P70		3	P44	
4	P71		4	P45	
5	P72		5	P46	
6	P73		6	P47	
7	P74		7	P30	
8	P75		8	P31	
9	P76		9	P32	
10	P77		10	P33	
11	AVss		11	P34	
12	P80		12	P35	
13	P81		13	P36	
14	P82		14	P37	
15	P83		15	P10	
16	P84		16	P11	
17	PA0		17	P12	
18	PA1		18	P13	
19	PA2		19	P14	
20	PA3		20	P15	
21	PA4		21	P16	
22	PA5		22	P17	
23	PA6		23	P20	
24	PA7		24	P21	
25	Vcc		25	P22	
26	GND		26	P23	
CN2			CN4		
1	Vcc		1	P24	
2	GND		2	P25	
3	PB0		3	P26	
4	PB1		4	P27	
5	PB2		5	P50	
6	PB3		6	P51	
7	PB4		7	P52	
8	PB5		8	P53	
9	PB6		9	P60	
10	PB7		10	P61	
11	FWE		11	P62	
12	MD2		12	CKOUT	
13	P90		13	/STBY	
14	P91		14	/RES	
15	P92		15	NMI	
16	P93		16	P63	
17	P94		17	P64	
18	P95		18	P65	
19	P40		19	P66	
20	P41		20	/M RES	